Compatible Sony Camera Models B

Godox Camera Flashes: MF-R76S/TT685S/TT685IIS/V860IIS/V860IIIS/V1S/V1ProS

Mode	Type	Camera Flashes							2.4G Transmitter & Receiver Flash Units							Auto Focus Assist Beam	Note
		TTL Flash			M Flash			Multi Flash	TTL Flash			M Flash			Multi Flash		
		Front-curtain Sync	Rear-curtain Sync	HSS	Front-curtain Sync	Rear-curtain Sync	HSS		Front-curtain Sync	Rear-curtain Sync	HSS	Front-curtain Sync	Rear-curtain Sync	HSS			
α77II	SLR Cameras	√	√	√	√	√	√	√	√	√	√	√	√	√	√	Unavailable	
α99		√	√	√	√	√	√	√	√	√	√	√	√	√	√	Unavailable	
α77		√	√	√	√	√	√	√	√	√	√	√	√	√	√	Unavailable	
DSC-RX10		√	√	√	√	√	√	√	√	√	√	√	√	√	√	Unavailable	
α350		√	√	√	√	√	√	√	√	√	√	√	√	√	√	Unavailable	
α7R	Mirrorless Cameras	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
α6400		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
α6500		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
α6000		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
α7RII (4.0)		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
α7RIII		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
α7M3		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
α9		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
α7RIV		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
α7R5		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
α7MIV		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
ZV-E10		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
A9III		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	
A7C		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	